




Typical Applications:

FOOD & BEVERAGE
PHOTOGRAPHIC
DEIONIZED WATER
R.O. MEMBRANE
PRE-FILTRATION
PROCESS WATER
FINE CHEMICALS
PLATING CHEMICALS
WASTEWATER

Flow Rate



High Purity - PPPleated Polypropylene Cartridge

Filter Data Sheet

Pleated Polypropylene Cartridges are designed for use in most applications where absolute rated pleated filtration is needed. Designed to hold 6.5 square feet of filtration media, our High Purity - PP Cartridge is a great value. These cartridges are constructed with 100% polypropylene materials and assembled using the latest thermal bonding equipment. Efficiency ratings to 99.98% (Beta 5000)

Construction Materials

Filtration Media	. Polypropylene
Support Media	Polypropylene
End Caps	Polypropylene
Center Core	Polypropylene
Outer Support Cage	. Polypropylene
O-Rings/Gaskets	Buna, Viton, EPDM,
	Silicone, Teflon®

Sanitization/Sterilization

Filtered Hot Water	80°C for 30 min.
Steam Sterilization	121°C for 30 min.
	multiple cycles

Encapsulated Viton

Chemicals: Cartridges are chemically compatible with most chemicals and sanitizing agents.

Note: Stainless steel insert option needed for all cartridges being hot water sanitized or steam sterilized.

Dimensions

Length: 10 to 40 inches (25.4 to 101.6 cm) nominal Outside Diameter: 2.70 inches (7.0 cm) nominal

Maximum Recommended Operating Conditions

Change Out......P 35 PSI Temperature......176°F (80°C)

FDA Listed Materials

Manufactured from materials which are listed for food contact applications in Title 21 of the U.S. Code of Federal Regulations.

Toxicity

All polypropylene components meet the specifications for biological safety per USP Class VI - 121°C for plastics.

Ordering Information

	_							
PP	Pore Size	Α	Length	C	End Cap Code	O-Rings/Gaskets	-	Adders
	0.2		10 (25.4 cm)		2 = DOE Flat Gasket	B = Buna		I = Stainless Steel Insert
	0.45		20 (50.8 cm)		3 = 222 w/ Fin	E = EPDM		HP = Heavy Poly Core
	1.0		30 (76.2 cm)		4 = 222 w/ Flat Cap	S = Silicone		FG = Glass Reinforced PP Core
	2.0		40 (101.6 cm)		5 = 222 w/ Spring	V = Viton		SS = Stainless Steel Core
	5.0				6 = 226 w/ Flat Cap	T = Teflon® Endcapsulated Viton		R = 18 Megohm Rinse
	10.0				7 = 226 w/ Fin			
	20.0				8 = 226 w/ Spring			
	40.0				16 = 213 Internal O-Ring			

www.culligan.com